

# GALLET HELMET ADAPTERS

USER MANUAL



## SAFETY NOTICE

The product must only be used by personnel in good health and trained in the use of respiratory protective equipment. Individuals with beards or large sideburns may not obtain an adequate seal. The face mask must be maintained, serviced and tested as described in this user manual, Interspiro service manuals and Interspiro test instructions.



## INTERSPIRO IS NOT RESPONSIBLE FOR

COMBINATIONS OF PRODUCTS UNLESS PUT TO MARKET BY INTERSPIRO


IN CHANGES OR ADAPTATIONS MADE TO THE PRODUCT BY A THIRD PARTY



Changes to this document - necessitated by typographical errors, inaccuracies of current information or improvements and changes of equipment - may be made at any time without prior notice. Always refer to www.interspiro.com for product updates, document updates and service bulletins. Exposure to extreme conditions may require other actions than described in this manual. The guarantees and warranties specified in the conditions of sale are not extended by this Safety Notice.

#### 2 **MARKINGS** [FIG. 1]

 $\mathbf{R} = \text{Right}$ 



#### 3 MOUNT HOLDERS ON FACE MASK

- 1. Remove head harness, buckles, holders and pins from the face mask.
- Remove the screw that holds the frame halves together on one side of the face mask.
- 3. Assemble the link arm on the helmet adapter to the visor frame. Use one of the screws supplied with the helmet adapter.

The left hand link arm is marked with a "L", while the right hand link is marked with a "R".

4. Repeat with the other side of the face mask.

```
NOTE! THE SCREWS ARE INSERTED FROM THE SIDE WITHOUT THREAD INSERT
```

NOTE! AFTER MOUNTING THE FACE MASK MUST BE CHECKED TO BE LEAK TIGHT ACCORDING TO INTERSPIRO TEST INSTRUCTIONS.

# **4 DONNING THE FACE MASK**

- 1. Put on the Gallet helmet (see helmet user manual).
- 2. Put on the breathing apparatus (see breathing apparatus user manual).
- 3. Pull out the orange hand wheels and turn them according to the arrows to fully extend the helmet adapters. (See illustration below.)



- 4. Push the face mask against the face.
- 5. Hook the link arms on the helmet adapter into the notches on the sides of the helmet.



 At the same time, pull out both orange hand wheels and turn them simultaneously towards the "+" sign to tighten the helmet adapters. (See illustration below.)



Do not over tighten the helmet adapters. Make sure that there is no hair in between the sealing surface of the face mask and the skin.

NOTE! CHECK THE FACE SEAL BEFORE USE (SEE FACE MASK USER MANUAL).

# **5 DOFFING THE FACE MASK**

- 1. If applicable, switch off the positive pressure.
- 2. Pull out the orange hand wheels and turn them according to the arrows.
- 3. Disconnect the hooks on the helmet holders from the helmet and remove the face mask.

# **INTERSP**IRO

### CENTRAL EUROPE

### AUSTRIA

INTERSPIRO GesmbH www.interspiro.de Feldbacher Str. 3 A-8200 GLEISDORF AUSTRIA

TEL +43 (0)311 236 133 FAX +43 (0)311 236 133 22 E-MAIL info@interspiro.de

### GERMANY

INTERSPIRO GmbH www.interspiro.de Postfach 1220 D-76691 FORST/BADEN GERMANY TEL +49 (0)7251 8030 FAX +49 (0)7251 2298 E-MAIL info@interspiro.de

### SWITZERLAND

INTERSPIRO AG www.interspiro.de Güterstraße 47 CH-4133 PRATTELN SWITZERLAND TEL +41 61 827 99 77 FAX +41 61 827 99 70 E-MAIL info@interspiro.ch

### THE NETHERLANDS & BELGIUM INTERSPIRO BV www.interspiro.nl

Operetteweg 35 NL-1323 VK ALMERE **NETHERLANDS** TEL +31 (0)36 5363103 FAX +31 (0)36 5384809 E-MAIL infobv@interspiro.com NORTH & SOUTH AMERICA

INTERSPIRO Inc. www.interspiro-us.com 10225 82nd Avenue PLEASANT PRAIRIE WI 53158-5801 USA TEL +1 262 947 9901 FAX +1 262 947 9902 E-MAIL sales@interspiro-us.com

**UNITED KINGDOM & IRELAND** 

INTERSPIRO Ltd. www.interspiro.com 7 Hawksworth Road Central Park TELFORD Shropshire TF2 9TU UNITED KINGDOM TEL +44 (0)1952 200 190 FAX +44 (0)1952 299 805 E-MAIL infouk@interspiro.com

## SCANDINAVIA, ASIA/PACIFIC & MIDDLE EAST

SWEDEN NORDIC & EXPORT SALES DIVISION www.interspiro.com Box 2853 S-187 28 TÅBY SWEDEN TEL +468 636 51 00 FAX +46 8 636 51 99 E-MAIL info@interspiro.com

MALAYSIA NORDIC & EXPORT SALES DIVISION www.interspiro.com 305 & 305A Lorong Perak Taman Melawati 53100 KUALA LUMPUR MALAYSIA TEL +60 3 4105 8122 FAX +60 3 4105 3122 E-MAIL asiapacific@interspiro.com

📩 www.interspiro.com 📥